FK-380 MINI KEYBOARD User's Manual

















Introduction

FK-380 mini keyboard is one of the best computer input devices in the market today.

FK-380 is ergonomically designed allowing for comfortable use on table.

Please read carefully the information and instructions contained in this manual and you are sure to obtain a higher level of computing enjoyment.

Specification

- Plug and Play USB interface for easy and convenient usage.
- 2 USB ports let you plug multiple devices together.
- Compatible with Windows 2000 / Windows XP / Windows Vista / Windows 7.
- Key layout: 86/87 keys + 10 hot keys.
- 10 one-touch hot key to quickly access internet and multimedia function.
- Switch life: 10 million life cycle.
- Bounce Time: less than 10m sec.
- With a quite tactile feel.
- Non-skid rubber feet.
- Dimension: 303.8 * 151.2 * 22.7 mm.

Installation

- Plug USB connector onto the port on your computer.
- USB support Plug & Play, no need to restart computer.

Keys Description





Page: 2

Function Guide

 USB Hub: FK-380 support 2 USB hubs at upper of keyboard let you plug multiple devices together.

2. LED light:

- 2.1 Num Lock: when the LED is lighting, means keys switch to mode of number pad, Otherwise in generally mode.
- 2.2 Caps Lock: When the LED is lighting, means full keyboard on capitalized mode. Otherwise on lowercase mode.
- 2.3 Scroll Lock: When the LED is lighting, means scroll lock mode is on, the arrow keys would scroll the contents of a text window instead of moving the cursor.

3. Key Function:

- 3.1 PrtSc SysRq: Press **Fn & F10** together to have function of print screen function. Easy to catch hot copy from screen.
- 3.2 Scroll Lock: Press Fn & F11 together if you need to have function of "Scroll lock".
- 3.3 Pause Break: Press Fn & F12 together if you would to pause the screen.
- 3.4 Number pad: Press **Num lock** to switch keys (in block as picture at page2.) as number pad or generally keyboard.

3.5 Hot keys:

Internet keys:

■ Press to Internet web Home.

■ Press to open mail folder.

■ : Press to open "My computer" folder.

● Multimedia keys: **★ ▶ ■ ▶**/**| □**())× **□**((- **□**())+

Notice

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.